



# 5G CPE

**UF51**

Installation Guide

## Safety Precautions

Yeastar will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- The device must not be modified in any way.
- Do not place the device close to objects with naked flames.
- Do not place the device where the temperature is below/above the operating range.
- Do not power on the device or connect it to other electrical device when installing.
- Check lightning and water protection when used outdoors.
- Do not connect or power the equipment using cables that have been damaged.

## Related Documents


This Installation Guide only explains the installation of Yeastar UF51 5G CPE. For more functionality and advanced settings, please refer to the relevant documents as below.

Document	Description
UF51 Datasheet	Datasheet for UF51 5G CPE.
UF51 Administrator Guide	IT administrators can refer to the guide for instruction on how to log in the web GUI, and how to configure all the settings.

The related documents are available on Yeastar website: <https://www.yeastar.com>

## Declaration of Conformity

UF51 is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



For assistance, please contact  
Yeastar technical support:  
Email: [support@yeastar.com](mailto:support@yeastar.com)  
Tel: 86-592-5085280  
Fax: 86-592-5023065

## Revision History


Date	Doc Version	Description
July 28, 2021	V1.0	Initial version

# Contents


Packing List.....	4
Overview.....	5
Dimensions (mm).....	5
Serial & IO & Power Pinouts.....	6
LED Indicators.....	6
Reset Button.....	7
Power Supply.....	8
Hardware Installation.....	9
SIM Card Installation.....	9
Waterproof Cover & Ethernet Cable Installation.....	9
Device Installation.....	10
Desktop.....	10
Wall Mounting.....	10
Pole Mounting.....	11
Login the Web GUI.....	13
Wireless Access.....	13
Wired Access.....	13

## Packing List


Before you begin to install the UF51 5G CPE, please check the package contents to verify that you have received the items below.




1 × UF51 Device




1 × PoE Injector




1 × Mounting Bracket




1 × Ethernet Cable



4 × Rubber Feet



1 × 8-Pin Pluggable  
Terminal Block



1 × Bottom Cover  
with Cable Gland




1 × Waterproof  
Rubber Ring




Wall Mounting Kits



2 × Hose Clamps



1 × Warranty Card




1 × Quick Start Guide




**If any of the above items is missing or damaged, please contact your sales representative.**

# Hardware Introduction


## Overview



## Dimensions (mm)



## Serial & IO & Power Pinouts



PIN	RS232 /RS485	DI	DO	Power	Description
1	---	IN	---	---	Digital Input
2	GND	GND	---	---	Ground
3	---	---	---	(-)	Negative
4	---	---	---	(+)	Positive (9-48V)
5	---	---	COM	---	Common Ground
6	---	---	OUT	---	Digital Output
7	RXD/B	---	---	---	RS232-RXD RS485-B
8	TXD/A	---	---	---	RS232-TXD RS485-A

## LED Indicators

LED	Indication	Status	Description
STATUS	Power & System Status	Off	The power is switched off
		Orange	Static: The system is startup
		Green	Static: The system is running properly
		Red	Static: The system goes wrong
5G	Cellular Status	Off	SIM card is registering or fails to register (or there are no SIM cards inserted)
		Green	Blinking slowly: SIM card has been registered and is ready for dial-up
			Blinking rapidly: SIM card has been registered and is dialing up now
			Static: SIM card has been registered and dialed up to 5G network
		Orange	Static: SIM card has been registered and dialed up to 4G network
Ethernet Port	Link Indicator (Orange)	Off	Disconnected or connect failure
		On	Connected
		Blinking	Transmitting data
	Rate Indicator (Green)	Off	100 Mbps mode
		On	1000 Mbps mode


## Reset Button

Function	Description	
	STATUS & 5G LED	Action
Reset	Static	Press and hold the reset button for more than 5 seconds.
	Static → Blinking	Release the button and wait.
	Off → Static Green	The device resets to factory default.

## Power Supply

UF51 can be powered by 802.3af standard PoE or 9-48VDC. **Both power supplies can't be used at the same time.**

**PoE Supply:** Follow the below picture to provide power supply via PoE injector. Besides, UF51 can also be powered by PoE switch.




**DC Supply:** Connect the DC power cable to terminal block, then connect the terminal block to DC interface to power the device.



## Hardware Installation

### SIM Card Installation


Insert the SIM card into the device according to the direction icon on the device. If you need to take out the SIM card, press into the SIM card and it will pop out automatically.




### Waterproof Cover & Ethernet Cable Installation

If you need to use UF51 outdoors, the waterproof cover and cable gland should be installed under the bottom of the device.


A. Install the rubber ring into the bottom of the device. Note that the round part needs to face the gap of bottom when installing, otherwise it may cause waterlogged.




B. Connect a round Ethernet cable to LAN1/WAN port, then pass the Ethernet cable through all parts of the cable gland and the bottom cover.



C. Fix the bottom cover to the bottom of the device with 4 screws. Note that the arrow behind the cover needs to face the bracket mounting screws.



**Note:** Bottom cover can be fixed with the device via the wiring behind the cover.




## Device Installation

UF51 supports multiple installation methods like desktop, wall mounting, pole mounting, etc. Before you start, make sure that your SIM card has been inserted and all cables have been installed.

**Note:** Do not connect device to power supply or other devices when installing.

### Desktop

When using indoors, pile 4 rubber feet into the gaps at the bottom of the device. The rough surface of rubber feet should face desktop.




### Wall Mounting

**Preparation:** mounting bracket(with 2 screws), wall plugs, wall mounting screws and other required tools.


A. Align the mounting bracket horizontally to the desired position on the wall, use a marker pen to mark four mounting holes on the wall, and then remove the mounting bracket from the wall.

**Note:** The connecting lines of adjacent points are at right angles.

- B. Drill four holes with a depth of 32 mm by using your drill with a 6 mm drill bit on the positions you marked previously on the wall.
- C. Insert four wall plugs into the holes respectively.
- D. Mount the mounting bracket horizontally to the wall by fixing the wall mounting screws into the wall plugs.




- E. Hang the device to the mounting bracket via bracket mounting screws on the back of device, then screw the 2 bracket screws to the bottom of the device.





## Pole Mounting

**Preparation:** mounting bracket(with 2 screws), hose clamps and other required tools.

- A. Loosen the hose clamp by turning the locking mechanism counter-clockwise.
- B. Straighten out the hose clamp and slide it through the rectangular rings in the mounting bracket, wrap the hose clamp around the pole.
- C. Use a screwdriver to tighten the locking mechanism by turning it clockwise.



- D. Hang the device to the mounting bracket via bracket mounting screws on the back of device, then screw the 2 bracket screws to the bottom of the device.



## Login the Web GUI

UF51 provides web-based configuration interface for management. If this is the first time you configure the device, please use the default settings below:

Username: **admin**

Password: **password**

## Wireless Access

A. Enable Wireless Network Connection on your computer and search for access point **"Router\_\*\*\*\*\*"** to connect it.

B. Open a Web browser on your PC (Chrome is recommended) and type in the IP address **192.168.1.1** to access the web GUI.

C. Enter the username and password, click "Login".




**If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.**



## Wired Access

Connect PC to UF51 LAN port directly or through PoE injector. The following steps are based on Windows 10 operating system for your reference.

A. Go to "Control Panel" → "Network and Internet" → "Network and Sharing Center", then click "Ethernet" (It may have different names).



B. Go to "Properties" → "Internet Protocol Version 4(TCP/IPv4) ", select "Obtain an IP address automatically" or "Use the following IP address", then assign a static IP manually within the same subnet of the device.



C. Open a Web browser on your PC (Chrome is recommended) and type in the IP address **192.168.1.1** to access the web GUI.

D. Enter the username and password, click "Login".



**If you enter the username or password incorrectly more than 5 times, the login page will be locked for 10 minutes.**